



---

**MOUNT THE CONVERSION KIT ON THE BOWL IN THE REVERSE  
MODE**  
**PLACE THE KIT BASE ON THE UPSIDE DOWN BOWL WITH THE  
GASKET BETWEEN. ALWAYS MAKE A LEAKING TEST TO BE SURE  
THAT GASKET IS MOUNTED CORRECTLY.**

---